

## CARE AND MAINTENANCE

Your Viking Sink marble top requires **MINIMAL** care to maintain its beauty. The surface is nonporous which resists staining. Routine cleaning with a damp cloth or sponge using a **NON-ABRASIVE** general purpose or foam cleaner is normally all that is needed. Harsh abrasive cleansers, lye solutions, bleaches, peroxides and chemical solvents are neither required nor recommended.

To maintain luster and make cleaning easier, periodic applications of paste wax or products designed for CULTURED MARBLE may be applied.

Minor abrasions and scratches may be removed by using a very mild automotive polishing compound or baking soda.

**For Matte Finish Only:** Minor abrasions and scratches may be removed by using a green scotch bright pad and gently sanding in a circular motion. We recommend applying Murphy's Soap Oil to bring color back to its original luster.

Deeper scratches and more extensive damages may require on-site repair by a qualified dealer representative, this will be charged at our standard service rate. See page 7.

Excessive hot water will crack sink around the drain, which is non repairable. Use of excessively hot water – **Over 140° F will void warranty** (120° F is recommended)

## INSTALLATION

### INSPECTION

Visually inspect for damage that may have been caused in transit. **All tops are to be checked upon receipt of delivery. DO NOT install a damaged top.**

### SIZING

Trial fit vanity top to cabinet and walls. If necessary, trim or shave cabinet top with a belt sander to assure top fits flat on the cabinet base. If sink fits to wall on one end and that wall corner is out of square, you may belt sand the end of the vanity top that fits to the wall. Care must be taken not to chip or remove too much material from the sink end when doing this procedure.

### INSTALLING FAUCET AND DRAIN

Install faucet and drain according to manufacturer's directions. Use a high-quality silicone caulk under the drain collar. **DO NOT USE PLUMBERS PUTTY; DO NOT OVERTIGHTEN DRAIN!!** Normally 1/8 to 1/4 turn past hand tight is sufficient. Remove excess silicone with denatured alcohol.

### INSTALLING THE VANITY TOP

Remove dust from top of cabinet and bottom of vanity top with denatured alcohol. Apply silicone to top corners of base cabinet. Carefully place vanity top onto cabinet base. Side splash should be installed last after all plumbing connections are made.

### CAULKING

Clean entire top with a mild household cleaner, and dry thoroughly. Apply thin bead of silicone caulk to seal joint next to wall and top of backsplash. Wipe off excess with denatured alcohol.